




# KLAX™ CABARET



## **KLAX Cabaret Cabinet Parts & Game Wiring Diagram**

*Supplement to the KLAX™ Universal Kit Installation Instructions (TM-348)*


This supplement provides information for ordering replacement parts for your KLAX game. The game wiring diagram is also reproduced in this supplement.

If you need technical assistance,  
call your distributor or Atari Games Customer Service  
at one of the following locations:

**United States:** (408) 434-3950  
Atari Games Corporation, 737 Sycamore Drive, Milpitas, CA 95036-1110  
(Monday-Friday, 7:30 a.m.-4:00 p.m. Pacific time)


**OR**

**Europe:** 062-52155  
Atari Games Ireland Limited, Tipperary Town, Ireland  
(Monday-Friday, 9:00 a.m.-5:30 GMT)



- Items Not Shown:**
- A047602-01 Main Harness Assy
  - A047603-01 Display Power Harness
  - A047604-01 Control Panel Harness Assy
  - 047594-02 Poster
  - TM-296 Video Display Service Manual
  - TM-348 Klax Universal Kit Installation Manual
  - CO-346-01 Cabaret Game Supplement
  - ST-347 Self-Test Label
  - 047586-01 Left Side Decal
  - 178126-002 Tamper-Proof Hex Key Driver
  - 178056-002 1/2-Inch Foam Tape

Figure 1 Front View of KLAX Cabaret Cabinet



**Figure 2 Rear View of KLAX Cabaret Cabinet**




Figure 3 KLAX Main Wiring Diagram