BONUS AT		
2000, 4000, 8000, pts. 3000, 6000, 12,000, pts. 4000, 8000, 16,000, pts. 5000, 10,000 20,000, pts.	SW. 1 ON OFF ON OFF	SW. 2 ON ON OFF OFF
METHOD OF PLAY		
1 COIN, -1 PLAY 2 COINS- 1 PLAY 1 COIN- 3 PLAYS 2 COINS- 3 PLAYS	SW. 3 ON OFF ON OFF	SW. 4 ON ON OFF OFF
BONUS NO BONUS CROSS HATCH RAM-ROM TEST ENCODER ALIGHNMENT	SW. 5 ON OFF ON OFF	SW. 6 ON OFF OFF ON
TIME OF PLAY		
45 SECONDS 60 SECONDS 75 SECONDS 90 SECONDS	SW. 7 ON OFF ON OFF	SW. 8 ON ON OFF OFF