



Ball Index Re.	166
Coin Re.	56
Ball Release	156
Lock Re.	66
Outsole Re.	176
Player Re.	186
Replay Re.	66
Reset Re.	66
Score Reset Re.	66
Shoot Again Re.	176
Target Re.	176
Tilt Re.	186
2nd Coin Re. (Latch)	76
2nd Coin Re. (Trip)	76
25¢ Re.	46
10¢ Re.	46
10¢ Re.	186
10¢ Re.	196
10¢ Re.	196
10¢ Re.	236
10¢ Re.	246
10¢ Re.	246
1 Point Re.	216
10 Point Re.	216
100 Point Re.	206
300 Re.	206

Ball Count Reset	76
Ball Count Stop Unit	126
Ball Release	166
Coin Lockout	116
Drum Units (8)	96 To 116
Unit Bumpers (3)	86 To 96
Knocker	87
Left Flipper	256
Left Kicker	256
Playmeter	66
Relay Bank Reset	86
Replay Stop Unit	126
Replay Unit Reset	76
Right Kicker	256
Right Flipper	266
Target Advance Call	196

ABBREVIATIONS USED			SWITCH SYMBOLS	
Adj - Adjustment	G.O. - Game Over	Pr - Relay	+	NORMALLY OPEN SWITCH CLOSED WHEN ENERGIZED.
Adv - Advance	Imp - Impulse	R - Right		
Amp - Amperes	Ind - Index	Re - Relay	-	NORMALLY CLOSED SWITCH OPEN WHEN ENERGIZED.
Bk - Break	L - Left	R.O. - Roll Over		
Bot - Bottom	MA - Make	R.P. - Replay	⊕	SWITCH CONTAINED WITHIN A CIRCLE INDICATES OPERATION BY A MOTOR CAM.
DU - Drum Unit	M-B - Make-Break	S.U. - Stop Unit		
E.G.S. - End of Stroke	Pos - Position	Sw - Switch	⊕	SWITCH.
WIRE COLOR CODE				
A - Red	G - Green	O - Orange		
Bk - Blue	W - White	Bl - Black		
Y - Yellow	Br - Brown	Gr - Grey		
EXAMPLE: - W-R INDICATES WHITE WIRE WITH A RED TRACER.				